

FIG. 2A

്മ





FIG. 2B



i




FIG. 4






FIG. 5

USER MODE APPS "STANDARD" USER MODE API 610 SERVICE PROVIDER **CLASS DRIVER CLIENT MINIDRIVER** BLUETOOTH BUS DRIVER INTERFACE 620 **BLUETOOTH BUS** 630 DRIVER **BLUETOOTH HCI** 640 BLUETOOTH HOST 650 CONTROLLER DRIVER LINK MANAGER CONTROL DRIVER 660 AUDIO DEVICE AUTHENTICATION TRANSPORT BUS 680 **BLUETOOTH HARDWARE** AND FIRMWARE

BLUETOOTH SOFTWARE STACK 600

FIG. 6








FIG. 10




FIG. 11




FIG. 12




FIG. 13




FIG. 14




FIG. 15

